

1062 Fourth Avenue Sidney, Ohio 45365 Phone: (937) 492-9187 Fax: (937) 498-4837

# **J3H-3000**

#### START-UP RECOMMENDATIONS

### Polypropylene Homopolymer

**Barrel Temperatures** 

Nozzle	C4	C3	C2	C1
400° F / 205° C	420° F / 215° C	390° F / 200° C	355° F / 180° C	340° F / 170° C

For harder to fill parts the temperatures may have to be increased. Keep lower temperatures in the rear zones to allow venting through hopper.

#### **Melt Temperature**

Maximum temperature with a hand pyrometer should be 365° F to 440° F. (185° C to 226° C)

#### **Mold Temperature**

Typically 80° to 110° F. (27° C to 43° C)

## **Injection Pressure**

The preferred range is 20 to 60% of machine capacity. Pressure should be sufficient to fill the mold without hesitation or flashing.

# **Holding Pressure**

Setting should be lower than boost pressure with a minimum amount of time to prevent over-packing of the part.

# **Injection speed**

Slow to medium speed to prevent excessive shear on the material.

#### **Cushion**

Maintain at 5-10mm to provide enough material for consistent parts.

#### **Decompression**

Use only when necessary to prevent nozzle drool.

#### **Screw RPM**

Screw should stop 1 to 2 seconds before mold open. A lower RPM is preferred for mixing and uniform melt temperature.

Disclaimer: The user assumes all risk and liability concerning the use of these recommendations.