



# PROCESS/START-UP RECOMMENDATIONS

# **Filled Polypropylene**

### **Barrel Temperatures**

Nozzle	C4	C3	C2	C1
410° F / 210° C	420° F / 215° C	420° F / 215° C	$410^{\circ}  F  /  210^{\circ}  C$	380° F / 193° C

For harder to fill parts temperatures may have to be increased. Keep lower temperatures in the rear zones to allow venting through the hopper.

### Melt Temperature

Maximum temperature with a hand pyrometer should be 390° F to 480° F (198° C to 248° C).

### **Mold Temperature**

Minimum "A" surface steel temperature 120° F to 140° F (49° C to 60° C).

### **Injection Pressure**

The preferred range is 50 to 60% of machine capacity. Pressure should be sufficient to fill the mold without hesitation or flashing.

### **Holding Pressure**

Setting should be lower than boost pressure with a minimum amount of time to prevent over-packing of the part.

### **Injection speed**

Slow to medium speed to prevent excessive shear on the material.

# Cushion

Maintain at 0.25"-0.50" (6-12mm) to provide enough material for consistent parts.

### Decompression

Use only when necessary to prevent nozzle drool.

### **Screw RPM**

Screw should stop 1 to 2 seconds before mold open. A lower RPM is preferred for mixing and uniform melt temperature.

### Drying

Material should be dried for a minimum of 2 hours and a maximum of 4 hours at 212° F (100° C).

Disclaimer: The user assumes all risk and liability concerning the use of these recommendations.