

1062 Fourth Avenue Sidney, Ohio 45365 Phone: (937) 492-9187 Fax: (937) 498-4837

# JH-ST

#### START-UP RECOMMENDATIONS

# Polypropylene

**Barrel Temperatures** 

Nozzle	C4	C3	C2	C1
420° F / 215° C	440° F / 225° C	430° F / 220° C	400° F / 205° C	390° F / 200° C

Keep lower temperatures in the rear zones to allow venting through hopper.

### **Melt Temperature**

Maximum temperature with a hand pyrometer should be 470° F to 530° F. (243° C to 276° C)

# **Mold Temperature**

Typically 80° to 110° F. (27° C to 43° C)

### **Injection Pressure**

The preferred range is 20 to 60% of machine capacity. Pressure should be sufficient to fill the mold without hesitation or flashing.

# **Holding Pressure**

Setting should be lower than boost pressure with a minimum amount of time to prevent over-packing of the part.

#### **Injection speed**

Slow to medium speed to prevent excessive shear on the material.

#### Cushion

Maintain at 5-10mm to provide enough material for consistent parts.

### Decompression

Use only when necessary to prevent nozzle drool.

#### **Screw RPM**

Screw should stop 1 to 2 seconds before mold open. A lower RPM is preferred for mixing and uniform melt temperature.

Disclaimer: The user assumes all risk and liability concerning the use of these recommendations.